

Operating Instructions



It is important that you read this carefully before attempting the Setup!


One time Polyester-Skin Attachment:

- 1) Place the frame in an open area.
- 2) Partially expand frame to arms length by grabbing two corner legs.
- 3) Unfold Polyester-Skin™ and place it over the partially expanded frame.
- 4) Locate one of (4) Velcro corners on the skin.
- 5) Attach skin to the corner leg by aligning the Velcro, repeat on all (4) corners.
- 6) Locate the (4) leading edge snap-tights and secure to the frame.

Note: When assembling be careful not to let polyester-skin™ touch the ground to prevent dirt and staining.

The Setup

Place the shelter in the center of the area to be covered.



STEP

Partially expand frame to arms length by grabbing two corner legs. Set down.



2

STEP

Position yourself between the corner legs and locate the bottom diamond shape scissor bars.



3

STEP

Lift at bottom location and step backwards until shelter is fully opened



4

STEP

Lock each corner by placing left hand on the top of the leg (push-down) and position right hand under sliding corner bar (push-up) until locked into place.



5

STEP

Extend each telescopic leg by stepping on footplate and simultaneously lifting outer-leg to locked position. (extend fully)



6

STEP

ALWAYS ANCHOR! To secure on grass or dirt, locate footplate, insert spike through hole, use hammer to drive spike. For hardpan anchoring; see website.

Quick Tips:

- * Telescopic legs feature more than one height-adjustment.
- * Lock corner sliders before extending telescopic legs.
- * To prevent damage... frame should never be forcefully expanded, nor should corner sliders be forcefully locked.
- * ALWAYS be sure that frame is securely anchored. Even the slightest wind will lift the shelter causing frame damage and or serious injury. The warranty does not cover damage due to wind, rain or user neglect.

Take Down:

- 1) Remove spikes or weighted anchors.
- 2) Lower the telescopic legs by pushing and releasing each red U-Push™ lever.
- 3) Release each red corner slider.
- 4) Position yourself between two corner legs. Grab upper scissor bars.
- 5) Lift and walk inward until frame is totally folded. (Do not force)
- 6) Place in wheel Spin-Bag™.

Note:

- * Polyester-Skin™ can be left on the frame.
- * Be sure skin is clean and dry before storage.
- * Never force frame action. A gentle lifting and shaking motion will aid in operation.
- * Shelter can be leveled on slope by adjusting leg height position as needed.